EPB Caliper – Manual wind back procedure

1. Disconnect the EPB motor plug from the motor.



2. Use a 5mm Allen key and remove the EPB motors from the back of the calipers.

3. Once the EPB motor is removed use a 6mm allen key to turn the gear in the back of the caliper. Turn / Rotate clockwise until it comes to a stop.



4. Re-Install the motors back onto the calipers.

5. Re-Install the EPB motor plug into the motor.